



128

129


130

131

132





STEERING ANGLE SENSOR



INSTRUMENT CLUSTER -ELECTRO-MECHANICAL


SOLID STATE

ELECTRICAL LOAD CONTROL UNIT




ZONE F-14  
LEFT OF RELAY  
BOX AT LH  
INTERIOR  
KICK PANEL

ZONE B-276  
AT RH  
INTERIOR  
KICK PANEL



ZONE F-288  
AT RH  
INTERIOR  
KICK PANEL

TO GROUND



128

129

130

131

132