

50


51

52


53

54

55

IDLE SPEED
CONTROL
SOLENOIDAIR
CHARGE
TEMP.
SENSORTHROTTLE
POSITION
SENSORPOWER
STEERING
PRESSURE
SWITCHMAP
SENSORENGINE
COOLANT
TEMP.
SENSORPRESSURE
FEEDBACK EGR
(CALIF. ONLY)VIP TEST
CONNECTORS.T.L.
TERMINAL

LG/R	26	HEAT CONTROL, MAP, TPS
LG/Y	46	MAP, ACT. TPS, PFE, EGR, P/S SW., NEUTRAL/CLUTCH SW.
Y/BL	27	PFE EGR (CALIF. ONLY)
W/R	7	ECT
W/GN	45	MAP
BR/R	24	P/S SW.
W/R	40	ECT
W/BL	18	FUNCTION INDICATOR LAMP (MIL)
O/Y	28	VIP SELF TEST
O	9	VIP SELF TEST
GN	58	A/C RELAY
Y/BL	59	FUEL INJ. 3-5, 6
R/BK	27	FUEL INJ. 1-6 ISC SOLFROM EEC POWER RELAY
R/BK	57	FUEL INJ. 1-6
Y	35	ACT
LG/BK	47	TPS
Y	21	ISC
W/R	58	FUEL INJ. 1, 2, 4
R	54	INTEGRATED RELAY CONTROL
LG	37	FUEL PUMP RELAY MODULE
LG	52	HEADF RELAY
PK	55	EDF RELAY
Y/GN	4	TFI MODULE
BK	56	TFI MODULE
W	18	TFI MODULE
BR	56	TACH. CHECK
PK/BK	10	INTEGRATED RELAY CONTROL MOD., AC. PRESS. SW.
W/BL	9	FUEL TANK UNIT
W/BK	31	CANISTER PURGE
W	33	EGR SOLENOID (CALIF. ONLY)
GN/R	19	HEGO SENSOR
BK/W	40	BATTERY GROUND, HEGO
BR/R	3	SPEED SENSOR, HEAT CONTROL, SPEED CONTROL
BL/W	6	SPEED SENSOR, HEAT CONTROL, SPEED CONTROL
BK/Y	60	BATTERY GROUND
BL/R	1	ROOM FUSE
R/BL	30	NEUTRAL SWITCH, HEAT CONTROL
BR/GN	54	CLUSTER (DISPLAY)
BK/LG	49	HEGO GROUND

ENGINE ELECTRONIC CONTROL
(EEC IV)12A581 TO GROUND
BK/LG G105TO 10B942
ZONE 56-E
OR
ZONE 82-D

50

51

52

53

54

55

SPOUT TEST
CONNECTOR

TO GROUND

A/C
PRESSURE
SWITCHCANISTER
PURGE
SOLENOIDEGR
SOLENOID
(CALIF. ONLY)HEGO
SENSORVEHICLE
SPEED
SENSORWATER
TEMP.
SWITCHLOW OIL
LEVEL
SENSOR

CAPACITOR

OIL
PRESSURE
SENSORWATER
TEMP.
SWITCH