
94
95
96
97
98
99
HAZARD FLASHER SWITCH
CLUTCH INTERLOCK SWITCH (MTX ONLY)
IGNITION SWITCH
HEADLAMP SWITCH
FOG LAMP RELAY (GT ONLY)
FOG LAMP RELAY (CANADA GT ONLY)
DAYTIME RUNNING LAMPS MODULE (GT CANADA ONLY)
DAYTIME RUNNING LAMPS MODULE (GL & LX CANADA ONLY)
TO 14290 ZONE 10-F (GL) OR ZONE 41-F (LX)
(LX MTX)
(CAN)
(GT)
(ATX) (MTX)
TO JOINT BOX ZONE 78-B
TO GROUND
TO REAR HARNESS ZONE 117-F
REAR WIPER/ WASHER SWITCH
REAR WINDOW DEFROSTER SWITCH
REAR WINDOW DEFROSTER RELAY
FUEL PUMP RELAY (GL, GT)
STOP/TAIL LAMP CHECKER
I.P. LAMP DIMMER
STEERING ANGLE SENSOR (GT ONLY)
A
B
C
D
E
F
FRAME 18 OF 24
FPS-12136-91Z