
116
117
118
119
120
121
REMOTE CONTROL MIRROR SWITCH
R.H. LAP BELT BUCKLE LAMP
PREMIUM SOUND AMPLIFIER
TO RADIO
SOLID STATE
SUB WOOFER AMPLIFIER
SUB WOOFER
R.H. REAR SPEAKER
R.H. REAR LIMIT SWITCH & PASSIVE RESTRAINT MOTOR
REAR FOOT LAMP
POWER ANTENNA ASSEMBLY
LUGGAGE COMPARTMENT LAMP SWITCH
LUGGAGE COMPARTMENT LAMP
R.H. DOOR SWITCH
A
B
C
D
E
F
POWER DOOR LOCK RELAY
TO 10B942 ZONE 98-F OR ZONE 70-F (ELECTRONIC CLUSTER)
POWER SEAT SWITCH/ LAP BELT BUCKLE SWITCH
PASSIVE RESTRAINT MODULE
L.H. REAR LIMIT SWITCH & PASSIVE RESTRAINT MOTOR
PASSIVE RESTRAINT WARNING SWITCHES
FUEL PUMP INERTIA SWITCH
FUEL TANK PUMP/SENDING UNIT
PARKING BRAKE SWITCH
L.H. DOOR SWITCH
FRAME 22 OF 24